


WEIGH MODULES WITHOUT LOAD CELLS

# RL931 (Round Top) RL933 (Ball Round Top)

Medium to Heavy Capacity

## Applications

- Medium to heavy capacity tanks, blenders, reactors and bulk inventory management
- Petroleum refining process control
- Chemical blending/batching



### Mount Only. Does Not Include Load Cell

The RL93 Series mounting assembly utilizes the RL93 load cell and foot plate to provide an unmatched level of performance in tank and hopper weighing applications. The RL93 Series mount is ideally suited for indoor and outdoor process control operations with medium to heavy capacities. Modules are available with ball mount, round or square mount, nickel-plated or stainless steel construction.

### Order Information: Stainless Steel



| Nominal Capacity                     | Part # | Price   |
|--------------------------------------|--------|---------|
| <b>RL931S / Including Base Plate</b> |        |         |
| 5t                                   | 161177 | Consult |
| 10t                                  | 161183 | Consult |
| 15t                                  | 161189 | Consult |
| 20t                                  | 161195 | Consult |
| 25t                                  | 161201 | Consult |
| <b>RL933S / Including Base Plate</b> |        |         |
| 5t                                   | 161181 | Consult |
| 10t                                  | 161187 | Consult |
| 15t                                  | 161193 | Consult |
| 20t                                  | 161199 | Consult |
| 25t                                  | 161205 | Consult |
| <b>Base Plate Only / RL93S</b>       |        |         |
| 5 - 25 t                             | 161175 | Consult |

Note: Refer to page 237 for load cell information



### Order Information: Nickel

| Nominal Capacity                     | Part # | Price   |
|--------------------------------------|--------|---------|
| <b>RL931N / Including Base Plate</b> |        |         |
| 5t                                   | 161176 | Consult |
| 10t                                  | 161182 | Consult |
| 15t                                  | 161188 | Consult |
| 20t                                  | 161194 | Consult |
| 25t                                  | 161200 | Consult |
| <b>RL933N / Including Base Plate</b> |        |         |
| 5t                                   | 161180 | Consult |
| 10t                                  | 161186 | Consult |
| 15t                                  | 161192 | Consult |
| 20t                                  | 161198 | Consult |
| 25t                                  | 161204 | Consult |
| <b>Base Plate Only / RL93N</b>       |        |         |
| 5 - 25 t                             | 161174 | Consult |

Note: Refer to page 237 for load cell information



RL933



RL931