

Astra Cables

The Astra may communicate by RS-232 connection to a PC. It may also communicate to another Astra scale for the purpose of copying data from one machine to another.

The cable pin assignments are listed below for several types of cables. Black Box and Radio Shack part numbers are provided for each cable to facilitate purchasing a pre-fabricated cable.

<i>Astra to PC and Astra to Astra</i> Null Modem Cable				Black Box Part Number www.blackbox.com	Radio Shack Part Number www.radioshack.com
<u>Astra</u>	<u>Cable</u>	<u>Cable</u>	<u>PC or Astra</u>		
9-pin Male	9-pin Female	—————	9-pin Female	EYN257H-0006-FF	9-pin Female to 9-pin Female cable 26-152B
	RXD 2	—————	3 TXD		9-pin M/F Null Modem adapter 26-264B
	TXD 3	—————	2 RXD		
	SG 5	—————	5 SG		
<i>Astra to PC</i> Null Modem Cable					
<u>Astra</u>	<u>Cable</u>	<u>Cable</u>	<u>PC</u>		
9-pin Male	9-pin Female	—————	25-pin Female	EVNBPC-0006-FF	
	RXD 2	—————	2 TXD		
	TXD 3	—————	3 RXD		
	SG 5	—————	7 SG		